



Valeo starter motor

- | | | |
|----------------------------------|---|-----------------------------------|
| 1 Bush | 11 Washer - 2 off | 21 Starter pinion/clutch assembly |
| 2 Screw | 12 Commutator cover | 22 Bush |
| 3 Drive housing | 13 Rubber plug | 23 Circlip |
| 4 Pivot pin | 14 Brush spring | 24 Wave washer - 2 off |
| 5 Pinion engaging lever assembly | 15 Spacer | 25 Mounting bolt - 2 off |
| 6 Coil spring | 16 Brush holder | 26 Washer - 3 off |
| 7 Starter solenoid | 17 Seal | 27 Screw - 3 off |
| 8 Lock washer | 18 Brush set | 28 Circlip |
| 9 Nut | 19 Screw - 2 off | 29 Shim - as required |
| 10 Nut - 2 off | 20 Starter motor body and armature assembly | |